



Maintenance Instructions for Maxi Sweetlock Bulk Merchandising Scoop Bin

Cleaning:


- 1) Carefully bend the plastic lid out of the dispenser. Pull out the hinges according to picture 1 below.
Note: Do NOT mix the right and left hinges. The right hinge is gray and the left hinge is white.
- 2) Clean the hinges with a damp cloth.
NOTE: It is strongly recommended to NOT rinse or dip the hinges in water!



Clean the lid. Manual cleaning recommended.



Reassemble the hinges with the arrows pointing upwards.
Right = gray Left = white



Replace the lid in the bin with the longest of the alignment pegs pointing upward. See picture 3.

AKRIFORM
